



6500E 零部件清单

序号	代号	零部件名称	Description	数量
1	188F	通用汽油机	GENERAL GASOLINE ENGINE	1
2	12118/173F	气缸头盖螺栓	Bolt	1
3	12412/173F	气缸头盖螺栓垫圈	Washer	1
4	12410/173F	橡胶垫圈	Rubber seal	1
5	12220/173F	气缸头盖螺栓组件	Bolt	1
6	12212/182F	气缸头密封垫	Gasket, cylinder head	1
7	12200/182F	气缸头盖组合	Cylinder head cover Assy	1
8	11513/182F	通气管	Air duck	1
9	14210/182F	推杆组合	Pusher	2
10	14314/168F	气门间隙调节螺母	Lock nut	2
11	14312/168F	摇臂轴座销	Sleeve	2
12	14311/173F	气门摇臂	Valve rocker	2
13	14313/168F	气门间隙调节螺栓	Adjusting bolt for valve gap	2
14	14310/173F	气门摇臂装配组合	Valve rocker Massy	2
15	14221/173F	推杆导架	Pusher guide	1
16	12118/173F	气缸头螺栓	Flange bolt	4
17	14431/173F	气门油封	Air valve oil seal	1
18	14417/173F	排气门弹簧下座	Spring retainer, exhaust valve	1
19	14413/182F	气门弹簧座	Spring seat	2
20	14418/182F	锁夹		2
21	14416/173F	排气门顶帽	Cap, exhaust valve	2
23	12114/188F	进气门导管	Intake valve guide	1
24	12115/188F	排气门导管	Exhaust valve guide	1
25	12116/173F	气门导管卡圈	Circip	2
26	12100/188F	气缸头组合	Cylinder head Assy	1
27	12121/188F	气缸头密封垫	Gasket, cylinder head	1
28	18214/168F	排气口双头螺栓M8×34	Stud M8×34	2
29	27110/168F	火花塞F6TC	Spark plug F6TC	1
30	26114/AXQ1-190	调速臂	Regulating arm	1
31	26115/182F	调速拉杆	Pulling rod	1
32	26117/182F	复位拉簧	Back spring	1
33	26118/182F	微调速弹簧	Fine regulating spring	1
34	26210/182F	调速支撑板组件	Supporting plate set	1
35	26211/182F	调速支撑板	Supporting plate	1
36	26215/182F	调速弹簧	Regulating spring	1
37	GB5787-86	螺栓M6×12	Bolt M6×12	2
38	26116/168F	调速臂紧固螺栓	Lock bolt	1
39	GB818-85-H	螺钉M5×35	Screw M5×35	1
40	GB6177-86	螺母M6	Nut M6	1
41	25000/188F	调速控制系统	Regulating control system	1
42	12117/173F	气缸头定位销	Set pin	2
43	14411/188F	进气门	Intake valve	1
44	14421/188F	排气门	Exhaust valve	1
45	17218/4GF-3	进气口双头螺栓M6×M8×106	Stud M6×M8×106	2
46	17219/182F	进气口垫片	Inlet gasket	1
47	16122/188F	化油器接块	Connecting block	1
48	16113/188F	化油器垫片	Carburetor gasket	1
49	16351/188F	怠速调整螺钉	Idle adjustment screw	1
50	163320/188F	阻风门组合	Choke unit	1
51	16240/188F	化油器混合室体	Mixture chamber body	1
52	16244/188F	主喷油管	Main nozzle	1
53	16230/188F	浮子油针组合	Float needle	1
54	16243/188F	主喷油嘴	Main jet	1
55	16220/188F	浮子组合	Float	1
56	16216/188F	浮子室密封垫	Float chamber gasket	1
57	16211/188F	浮子室	Float chamber	1
58	16214/188F	浮子室放油螺钉	Float chamber drain Screw	1

59	16215/188F	浮子室放油螺钉垫圈	Washer	2
60	16210/188F	浮子室组合	Float chamber	1
61	16260/188F	节气门组合	Throttle unit	1
62	16355/188F	混合比调整螺钉弹簧	Spring, mixture adjustment screw	1
63	16354/188F	混合比调整螺钉	Mixture adjustment screw	1
64	16325/188F	阻风门防尘盖	Dust cover, choke	1
65	16212/188F	底部螺钉	Screw	1
66	16176/188F	化油器电磁阀密封垫	Gasket, carburetor magnetic valve	1
67	16310/188F	支架组件	Bracket	1
68	GB97. 1-85	平垫5	Flat washer 5mm	2
69	GB93-87	弹垫5	Spring washer 5mm	2
70	GB818-85	螺钉M5×12	Screw M5×12	2
71	16100/188F	化油器总成	Carburetors Says	1
72	19721/188F	下导风罩	Lead wind cover	1
73	GB5787-86	螺栓M6×12	Bolt M6×12	1
74	GB6177-88	螺母M6	Nut M6	2
75	17113/173F	空滤器垫片	Air cleaner gasket	1
76	14420/173F	挡油罩组件	Valve stem oil seal	1
77	GB/T6177. 2	六角法兰面螺母M10	Nut	4
78	GB/T6177. 1	六角法兰面螺母M8	Nut	4
79	11115/173F	放油螺塞	Drain plug	2
80	11116/173F	放油螺塞垫圈	Washer	2
81	GB/T276	轴承6207	Bearing 6207	1
82	11120/182F	曲轴油封	Oil seal, crankshaft	1
83	11100/188F	曲轴箱组合	Crankcase	1
84	26111/182F	调速摆杆	Regulating sway bar	1
85	26113/168F	调速摆杆垫片	Washer	2
86	26112/173F	调速摆杆锁夹	Split pin	1
87	GB3452. 1-92	O型密封圈13×1.4	O-ring 13×1.4	1
88	GB6177-86	螺母M10	Nut M10	1
89	27400/173F	机油传感器	Oil sensor	1
90	GB5787-86	螺栓M6×14	Bolt M6×14	3
91	25115/182F	调速轴	Regulating shaft	1
92	25117/182F	调速轴卡圈	Snap ring	1
93	25118/182F	调速从动齿轮垫片	Washer, driven gear	1
94	25111/182F	调速从动齿轮	Driven gear, regulator	1
95	25163/182F	飞块销	Pin	2
96	25141/182F	调速飞块	Flying block	2
97	25132/182F	调速滑套垫片	Washer	1
98	25131/182F	调速滑套	Sliding sleeve	1
99	25120/182F	调速从动齿轮组件	Driven gear, regulator assy	1
100	14122/188F	飞块弹簧	Extension spring	1
101	14100/188F	凸轮轴装配组合	Camshaft Assy	1
102	14315/173F	挺柱	Tappet	2
103	14127/188F	限位板销	Pin	1
104	14126/188F	限位板	Limit position panel	1
105	13117/182F	半圆键	Woodruff key	1
106	13111/182F	曲轴	Crankshaft	1
107	13114/182F	调速主动齿轮	Drive gear	1
108	13113/182F	正时主动齿轮	Timing driving gear	1
109	13110/182F	曲轴组合	Crankshaft assy	1
110	13116/190F	平衡轴	Balancing shaft	1
111	13121/182F	连杆	Shank	1
112	13122/182F	连杆盖	Connecting rod cover	1
113	13123/168F	连杆螺栓	Bolt	2
114	13120/182F	连杆组合	Connecting rod	1
115	13313/182F	活塞销挡圈	Piston pin circlip	2
116	13311/188F	活塞	Piston	1
117	13312/182F	活塞销	Piston pin	1
118	13411/188F	活塞环（一）	Piston ring (I)	1
119	13412/188F	活塞环（二）	Piston ring (II)	1

120	13422/188F	侧环	Side rail	2
121	13421/188F	衬簧	Expander	1
122	13420/188F	油环组合	Scraper ring set	1
123	13400/188F	活塞环组	Piston ring set	1
124	11114/182F	曲轴箱垫片	Gasket, crankcase	1
125	GB/T276	轴承6207	Bearing 6207	1
126	11113/173F	定位销	Set pin	2
127	11211/4GF-3	曲轴箱盖	Crankcase cover	1
128	11120/182F	曲轴油封	Oil seal, crankshaft	1
129	15512/173F	机油尺密封圈	Seal	1
130	15510/2.8GF-3	机油尺	Dipstick	1
131	15510/2.8GF-3	机油尺组件	Dipstick with seal	1
132	GB/T16674	螺栓M8×40	Bolt M8×40	7
133	11216/4GF-3	防尘板	Dust plate	1
134	11220/4GF-3	曲轴箱盖挡罩	Guard, crankcase cover	1
135	31995/2GF-3	十字六角带盘螺栓M5×12	Bolt M5×12	1
136	31113/4GF-3	定子外罩	Stator cover	1
137	31157/5GF-3	电机风扇	Generator fan	1
138	31120/5GF-3	转子总成	Rotor comp.	1
139	GB276-94	轴承6204-2ZN	Bearing 6204-2ZN	1
140	31100/5GF-3	定子总成	Stator Assy	1
141	31151/2.8GF-3	电机座	Generator stay	1
142	31130/2.8GF-3	电刷组件	Brush Assy	1
143	31153/2.8GF-3	十字六角带盘螺栓M5×14	Bolt M5×14	3
144	31140/2.8GF-3	电压调节器	Voltage regulator	1
145	31126/2.8GF-3	转子紧固螺栓平垫	Plain washer	1
146	31125/5GF-3	转子固定螺栓M10×265	Bolt M10×265	1
147	31112/5GF-3	定子紧固螺栓M6×175	Bolt M6×175	4
148	31152/2.8GF-3	电机后盖	Generator end cover	1
149	31153/2GF-3	十字六角带盘螺栓M5×12	Bolt M5×12	3
150	31511/2.8GF-3	纸垫φ5	Washer φ5	2
151	18000/5GF-3L	消声器总成	muffler	1
152	18230/2.8GF-3	消声器护罩组件（一）	Side hood	1
153	18620/2.8GF-3	消声器护罩组件（二）	Outer hood	1
154	18117/4GF-3	排气管	Exhaust pipe	1
155	18227/182F	消声器垫片	Gasket, exhaust pipe	1
156	18215/2.8GF-3	排气口垫片	Gasket, outlet	1
157	GB5787-86	螺栓M8×25	Flange bolt M8×25	2
158	GB6187-86	螺母M8	Nut M8	2
159	23300/182FD	飞轮部件	Flywheel	1
160	27200/182F	点火线圈组件	Ignition coil	1
161	GB5787-86	螺钉M6×30	Screw M6×30	2
162	27230/182F	熄火线	Engine stop cable	1
163	27210/182F	点火线圈	Ignition coil	1
164	27220/168F	火花塞帽	Spark plug cap	1
165	27220/173F	点火线圈组件	Ignition coil assy	1
166	23311/182F	飞轮组件	Flywheel	1
167	19111/182F	飞轮风扇	Flywheel fan	1
168	23316/182F	起动套	Starting flange	1
169	23317/173F	飞轮螺母M16×1.5	Nut M16×1.25	1
170	27500/168F	单向导通器	Diode	1
171	19210/182F	风扇罩组件	Fan hood assy	1
172	GB5787-86	螺栓M6×12	Bolt M6×12	5
173	23213/182F	轴位螺钉	Set screw	1
174	23216/182F	弹簧盖	Spring lid	1
175	23211/182F	摩擦弹簧	Friction spring	1
176	23215/182F	棘爪	Ratchet	2
177	23212/182F	棘爪弹簧	Ratchet spring	2
178	23217/182F	起动器卷轴	Starter rolls	1
179	23214/182F	盘簧	Spiral spring	1

180	23240/182F	外壳组件	Casing	1
181	23218/182F	拉绳	Rope	1
182	23231/182F	拉手	Pulling handle	1
183	GB5787-86	螺栓M6×8	Bolt M6×8	3
184	23100/4GF-3	反冲起动机	Recoil starter	1
185	23200/182F	反冲起动机总成	Recoil starter assy	1
186	24117/2V77F	线夹B	Plastic clip	1
187	11117/173F	橡胶圈	Grommet	1
188	17233/4GF-3	空滤器支架	Air cleaner stay	1
189	GB6187-86	螺母M6	Nut M6	2
190	17141/2.8GF-3	空滤器底盖	bottom cover	1
191	17124/2.8GF-3	滤芯	filter element	1
192	17124/2.8GF-3	滤芯	filter element	1
193	17110/2.8GF-3	空滤器盖组件	air cleaner cover assy	1
194	31161/2GF-3	扶手垫片	washer	2
195	17100/2.8GF-3	空气滤清器总成	Air cleaner Assy	1
196	16621/2.8GF-3	出油管(一)	oil pipe	1
197	16626/2.8GF-3	油管限位套	sleeve	2
198	16622/168F	油管夹	Tube clip	2
199	14416/173F	顶帽	cap of valve	2
200	31523/2GF-3	脚架支撑减震垫	cushion	2
201	16560/8.5GF-4	燃油传感器	Fuel sensor	1
202	16400/152F	燃油箱盖组合	Fuel filler cap comp.	1
203	16414/2GF-3	燃油箱盖密封圈	Packing ring	1
204	16610/168F	过滤杯	Fuel filter	1
205	GB/T16674	六角法兰面螺栓M6*25	bolt	4
206	16546/2GF-3	燃油箱垫圈	washer	4
207	16914/2GF-3	衬套	bush	4
208	16911/2GF-3	油箱减震垫	cushion	4
209	16510/2.8GF-3	燃油箱组件	Fuel tank	1
210	GB/T16674	六角法兰面螺栓M6*28	bolt	2
211	24145/182FD	压线板	wire press plate	1
212	16641/2GF-3	燃油开关	fuel switch	1
213	31251/5GF-4	面板后罩盖	control panel rear cover	1
214	32118/5GF-4	面板控制板	control panel	1
215	32100/5GF-4	机架组合	frame assy	1
216	GB/T16674	六角法兰面螺栓M6*40	bolt	4
217	GB/T6186.1	螺母M6	nut	4
218	GB/T5789	六角法兰面螺栓M6*12	bolt	4
219	32413/2GF-3	机架减震垫	cushion	4
220	32420/2.8GF-3	机组减震垫A组件	cushion	2
221	31262/2GF-3	开关线护套	Boot, switch wire	1
222	GB93	弹垫Φ4	Spring washer Φ4	3
223	GB818	螺钉M4×10	Screw M4×10	3
224	18314/2GF-4	防尘罩	Dust cap	1
225	31225/2GF-4	熄火开关	Ignition switch	1
226	31228/2GF-4	熄火开关防水罩	Waterproof cap	1
227	31231/2GF-4	接线柱8.3A, 12V	Binding post 8.3A,12V	2
228	GB5787	螺母M3	Nut M3	2
229	GB93	弹垫Φ3	Spring washer Φ3	10
230	GB97.1	平垫片Φ3	Flat washer Φ3	2
231	31226/5GF-4	电压表120V, 240V	Voltmeter	1
232	32450/2.8GF-3	机组减震垫B组件	cushion	2
233	31003/2.8GF-3	接线端子	Connector	2
234	31221/2.8GF-3	断路器, 25A	Circuit protector, 25A	1
235	GB5787	螺栓	Bolt	8
236	31223/2GF-3	插座(20A, 120V)	Consent (20A,120V)	3
237	GB6170	螺母M6	Nut M6	2
238	GB93	弹垫Φ6	Spring washer Φ6	2
239	GB97.1	平垫片Φ6	Flat washer Φ6	2
240	GB5787	螺栓M6×12	Bolt M6×12	1
241	24100/182FD	启动电机总成	starting motor assy	1

242	GB/T16674	螺栓M8×40	Bolt M8×40	2
243	24130/168FD	充电线圈组件	charger coil	1
244	32417/2. 8GF-3	扶手	handrail	1
245	32434/2GF-4	电瓶线 (+)	battery wire	1
246	32432/2GF-4	电瓶	battery	1
247	32434/2GF-4	电瓶线 (-)	battery wire	1
248	32433/5GF-4	电瓶压板	pressplate	1
249	41529/2GF-3	回位弹簧	back spring	1
250	16921/2GF-3	销轴	pin roll	1
251	60231/2GF-3	球形接头	ball connector	1
252	T515-0001	弹性圆柱销	pin	1
253	45420/2GF-3	车轮组件	wheel assy	2
254	31352/2GF-3	开口销	pin	2
255	31310/2GF-3	车轮轴	wheel axis	1
256	32231/2. 5GF-4	脚支撑	bolster	2
257	35368/AXQ1-200A	电流互感器	voltage and current transformer	1
258	31248/2GF-3	保险管	protective tube	1
259	31218/2GF-3	保护器	protector	1
260	35324/2GF-3	电压转换开关	voltage switch	1
261	31325/2GF-3	电源指示灯	indicator	1
262	GB/T5783	六角头螺栓M5X12	bolt	1
263	GB/T16674	六角法兰面螺栓M6X14	bolt	2