



E-01 曲轴箱组件 曲轴箱盖组件 CRANKCASE & CRANKCASE COVER ASSY



Id	PartNo	PartName	Description	Quantity	Price
E01-1	11110	曲轴箱组件	Crankcase	1	
E01-2	11113	曲轴箱盖定位销	Set pin $\phi 12 \times 16$	6	
E01-3	11114	曲轴箱垫片	Gasket, crankcase	1	
E01-4	11115	放油螺塞	Drain plug M20×1.5×15	2	
E01-5	11116	放油螺塞垫圈	Wahser, drain plug	2	
E01-6	11119	O型圈	O-ring $\phi 7 \times \phi 2$	1	
E01-7	11120	曲轴油封组件 (一)	Oil seal, crankshaft $\phi 60 \times \phi 45 \times 9$	2	
E01-8	11130/A1010	摆件油封组件 (一)	Oil seal, regulating sway bar $\phi 12 \times \phi 7.4 \times 3.2$	1	
E01-9	11143	油孔O型圈	O-ring $\phi 20 \times \phi 2$	1	

E01-10	11210	曲轴箱盖组件	Crankcase cover	1	
E01-11	11311	曲轴箱底盖	Crankcase bottom cover	1	
E01-12	11314	曲轴箱底盖密封垫	Sealing gasket for crankshaft case bottom cover	1	
E01-13	27400	机油传感器组合	Oil sensor	1	
E01-14	24146	吊环支架	Suspension bracket	2	
E01-15	12118/A1710	气缸头螺栓 M8×50	Bolt M8×50	13	
E01-16	T152-0112	螺栓M8×30	Bolt M8×30	8	
E01-17	T152-0010	螺栓M8×18	Bolt M8×18	2	


E-02 气缸头 气缸头盖总成 CYLINDER HEAD & CYLINDER HEAD COVER ASSY.



Id	PartNo	PartName	Description	Quantity	Price
E02-1	12118	气缸头螺栓M10×1.25×80	Bolt M10×1.25×80	4	
E02-2	12118	气缸头螺栓M10×1.25×87	Bolt M10×1.25×87	2	

E02-3	12118	气缸头螺栓M10×1.25×65	Bolt M10×1.25×65	4
E02-4	12120	气缸头密封垫组件	Cylinder head gasket assembly	2
E02-5	12130	气缸头组件	Cylinder head Assy	1
E02-6	12132	气缸头盖	Cylinder head cover Assy	1
E02-7	12133	气缸头螺塞	Rc3/4"	2
E02-8	12140	气缸头组合Ⅱ	Cylinder head AssyⅡ	1
E02-9	12142	气缸头盖Ⅱ	Cylinder head cover AssyⅡ	1
E02-10	12212	气缸头盖密封垫	Gasket, cylinder head cover	2
E02-11	12213	迷宫盖板	Gland, labyrinth	1
E02-12	12217	迷宫盖板密封垫	Gasket, labyrinth gland	1
E02-13	12250	迷宫隔板组件	Labyrinth cover assembly	2
E02-14	12271	簧片	Reed valve	1
E02-15	T152-0030	螺栓 M6×30	Bolt M6×30	1
E02-16	T152-0013	螺栓M6×25	Bolt M6×25	10
E02-17	12117/A1310	曲轴箱盖定位销	Crankcase cover Set pin φ12×16	4
E02-18	T210-0026	螺栓M3 6	Bolt M3×6	2
E02-19	12252	簧片限位块	Crankcase cover Set pin φ12×16	1


E-03 曲轴 活塞 连杆 CRANKSHAFT PISTON CONNECTING



Id	PartNo	PartName	Description	Quantity	Price
E03-1	13110	曲轴组件	Crankshaft assy	1	
E03-2	13120	连杆组件	Connecting rod assy	2	
E03-3	13131	连杆轴瓦	Bearing bush	4	
E03-4	13311	活塞	Piston	2	
E03-5	13312	活塞销	Piston pin	2	
E03-6	13313	活塞销挡圈	Piston pin circlip	4	
E03-7	13400	活塞环组合	Piston ring set	2	

E-04 凸轮轴装配组合 气门摇臂组合


COMBINATION OF CAMSHAFT & VALVE ROCKER



Id	PartNo	PartName	Description	Quantity	Price
E04-1	14100	凸轮轴组合	Camshaft assy	1	
E04-2	14210	推杆组件	Pusher	4	
E04-3	14311	气门摇臂	Valve rocker	4	
E04-4	14312	摇臂轴座销	Sleeve	4	
E04-5	T152-0118	摇臂螺栓M6×40	Bolt M6×40	4	
E04-6	14411	进气门	Intake valve	2	
E04-7	14412	排气门	Exhaust valve	2	
E04-8	14413	气门弹簧座（一）	Spring seat, exhaust valve	4	
E04-9	14414	气门弹簧	Valve spring	4	
E04-10	14418	气门锁夹	Valve collet	8	

E04-11	14420	挡油罩组件	Oil shield assembly	4	
E04-12	14350	液压挺柱组合	Hydraulic tappet	4	


E-05 机油泵 机油滤清器总成 OIL PUMP & OIL FILTER ASSEMBLY



Id	PartNo	PartName	Description	Quantity	Price
E05-1	15100	机油泵总成	Oil pump Assy	1	
E05-2	24143/A2514	启动电机定位销	Set pin $\phi 8 \times 10$	2	
E05-3	15118	泄压弹簧	Spring	1	
E05-4	15160	吸油盘组合	Oil suction pan	1	
E05-5	15161	吸油盘堵头	Oil suction disc plug	2	
E05-6	15162	吸油盘连接钢管	Oil suction plate connecting sheel pipe	1	
E05-7	15200	机油滤清器总成	Oil filter Assy	1	
E05-8	15212/A1310	管接头	Connector	1	

E05-9	15127	机油泵O型密封圈	Oil pump O-ring	1	
E05-10	15500	机油尺组合	Dipstick with seal	1	
E05-11	15610	机油塞组件	Oil plug	1	
E05-12	T152-0034	螺栓M6×25	Bolt M6×25	3	
E05-13	T152-0013	螺栓M6×20	Bolt M6×20	1	


E-06 化油器 汽油泵总成 CARBURETOR & GASOLINE PUMP ASSY.



Id	PartNo	PartName	Description	Quantity	Price
E06-1	16100	化油器总成	Fuel pump Assy	1	
E06-2	16113	化油器垫片	Carburetor gasket	2	
E06-3	16122	化油器接块	Connecting block	1	
E06-4	16332	阻风门回位弹簧 (二)	choke return spring	1	

E06-5	16660	燃油过滤器组件	Fuel filter assembly	1	
E06-6	16700	汽油泵总成	Gasoline pump assembly	1	
E06-7	16711	汽油泵支撑板	Gasoline pump support plate	1	
E06-8	16715	汽油泵出油管	Outlet pipe, fuel pump	1	
E06-9	16714	汽油泵进油管	Vacuum pipe, fuel pump	1	
E06-10	16716	汽油泵负压管	Inlet pipe, fuel pump	1	
E06-11	T152-0013	螺栓 M6×20	Bolt M6×20	2	
E06-12	T610-0004	钢带式弹性软管夹箍	Steel strip type elastic hose clamp	6	


E-07 空滤器总成 进气管组件 AIR CLEANER ASSY & INTAKE MANIFOLD MODULE



Id	PartNo	PartName	Description	Quantity	Price
E07-1	17100	空滤器总成	Air cleaner housing	1	
E07-2	17200	进气管组合	Inlet pipe	1	


[illegible]

2V90F E-08 消声器总成 MUFFLER ASSY



Id	PartNo	PartName	Description	Quantity	Price
E08-1	18000	消声器总成	Muffler assy	1	
E08-2	T354-0010	螺母M8	Nut M8	4	
E08-3	18214/A1310	排气口双头螺栓	Stud	4	
E08-4	18215	排气口垫片	Exhaust pipe gasket	1	
E08-5	T152-0112	螺栓 M8×30	BoltM8×30	2	

E-09 冷却系统 COOLING SYSTEM




Id	PartNo	PartName	Description	Quantity	Price
E09-1	19114	上导风罩	Deflector	1	
E09-2	19115	上导风罩(二)	Deflector II	1	
E09-3	19121	下导风罩	Lead wind cover	1	
E09-4	19131	下导风罩(二)	Lead wind cover II	1	
E09-5	19240	引风板组件	Induced draft fan	1	
E09-6	19213	风扇罩双头螺栓	Stud	4	
E09-7	19630	机油冷凝器组合	Condensator	1	
E09-8	19250	飞轮风扇组件	Flywheel fan	1	
E09-9	19210	风扇罩组件	Fan hood assy	1	

E09-10	19211	风扇罩	Fan hood	1	
E09-11	32170	卡子螺母	NutM6	2	
E09-12	19224	风扇罩减震胶套	Shock-absorbing rubber sleeve	2	
E09-13	19174	导风罩底板螺栓	Deflector boltM6×15	8	
E09-14	T152-0054	螺栓M6×16	Bolt M6×16	4	
E09-15	T152-0120	螺栓M6×60	Bolt M6×60	3	
E09-16	T152-0013	螺栓M6×20	Bolt M6×20	2	

E-10 飞轮部件


FLYWHEEL COMPONENT



Id	PartNo	PartName	Description	Quantity	Price
E10-1	19217	风扇罩盖	Fan cover	1	
E10-2	23300	飞轮组合	Flywheel	1	
E10-3	23319	飞轮螺母垫圈	Washer, flywheel $\phi 12\times 47\times 6$	1	

E10-4	T152-0119	飞轮螺栓M12×1.25×45	Bolt M12×1.25×45	1	
E10-5	24130	充电线圈组件	Charge coil assy 20A, 250W	1	
E10-6	T151-0011	螺栓M6×25	Bolt M6×25	2	


E-11 启动电机总成 STARTING MOTOR ASSY



Id	PartNo	PartName	Description	Quantity	Price
E11-1	T152-0116	螺栓M8×95	Bolt M8×95	2	
E11-2	24100	启动电机总成	Motor, starting	1	


E-12 调速从动齿轮组合（适用于机械调速）

SPEED REGULATING GEAR COMBINATION (IT IS SUITABLE FOR MECHANICAL SPEED REGULATION)



Id	PartNo	PartName	Description	Quantity	Price
E12-1	25100	调速从动齿轮组合	Driven gear, regulator assy	1	
E12-2	25112	调速滑套	Shaft sleeve	2	
E12-3	25118	调速从动齿轮垫片	Washer, driven gear	1	


E-13-1 机械式调速控制系统 MECHANICAL SPEED CONTROL SYSTEM



Id	PartNo	PartName	Description	Quantity	Price
E13-1-1	26100	调速控制组合	Controi group	1	
E13-1-2	26111	调速摆杆	Regulating sway bar	1	
E13-1-3	26114	调速臂	Regulating arm	1	
E13-1-4	26115	调速拉杆	Pulling rod	1	
E13-1-5	26116	调速臂紧固螺栓	Lock bolt M6×25	1	
E13-1-6	26117	复位弹簧	Back spring	1	
E13-1-7	26215	调速弹簧	Regulating spring 50HZ	1	
E13-1-8	26271	调速支架	Regulating board	1	


E13-1-9	26134	调速拉杆 II	Pulling rod II	1	
E13-1-10	26118	微调速弹簧	Fine regulating spring	1	
E13-1-11	23243	弹簧固定板	Fixing plate	1	
E13-1-12	T134-0061	螺栓M4×8	Bolt M4×8, 8.8级, GB/T 5783	2	
E13-1-13	T311-0002	螺母M6	Nut M6	1	

E-13-2 电控调速系统 Electronical speed control




E13-2-1	24310	电控调速器总成	Electric control governor assembly	1	
E13-2-2	T134-0034	螺钉M4×16	Bolt M4×16		

E-14 点火系统 IGNITION SYSTEM



Id	PartNo	PartName	Description	Quantity	Price
E14-1	27100	火花塞组合	Spark plug F6RTI-5	2	
E14-2	27200	点火线圈组合 (一)	Ignition coil assy I	2	
E14-3	31140	电压调节器组件	Voltage regulator 20A, 250W	1	
E14-4	T152-0030	螺栓M6×30	Bolt M6×30	4	

E-15 油管组件 OIL PIPE COMPONENTS



Id	PartNo	PartName	Description	Quantity	Price
E15-1	28518	输油管接头	Oil pipe joint	2	
E15-2	28610	高压油管组件	High-pressure oil pipe assembly	1	
E15-3	28613	高压油管联接螺栓	High-pressure oil pipe connecting bolts	2	
E15-4	28622	高压油管密封垫	High-pressure oil pipe sealing gasket	4	

2

L-1

[illegible]