

PARTS LIST

H23F

CONTENTS


0A. PARTS KIT	1
1. MAIN BOY	3
2. ENGINE	7
3. CARBURETOR, FUEL TANK	11
4. ACCESSORIES	13

2023. 07.




P/N 524361-1


H23F
0A. PARTS KIT




1



2




3



4

5




6

Ref. No.	Part No.	Part Name	Q'ty	Remarks
0A-1	247672	Cylinder Kit	1	Incl.5
0A-2	247673	Piston Kit	1	
0A-3	247660	Clutch Kit	1	
0A-4	247883	Carburetor Kit	1	
0A-5	247867	Carburetor Parts Kit	1	
0A-6	289279	Fuel Pipe Pick-up Ass'y	1	

H23F


1. MAIN BOY



Ref. No.	Part No.	Part Name	Q'ty	Remarks
1-1	362408	H23F	1	
1-2	277420	Guide Plate	1	
1-3	271888	Spacer Plate	1	
1-4	271889	Spacer	2	
1-5	277421	Spacer	4	
1-6	271890	Washer	6	
1-7	274280	Upper Blade	1	
1-8	274281	Lower Blade	1	
1-9	271896	Screw	4	
1-10	271897	Screw	2	
1-11	271899	Nut	4	Incl.14,15
1-12	274292	Cover of Blade	1	
1-13	274240	Left Handle Ass'y	1	
1-14	274241	Left Handle	1	
1-15	274242	Throttle Trigger	1	
1-16	274293	Right Handle Ass'y	1	
1-17	274294	Cushion A	1	
1-18	271906	Tail Pipe Cover	1	
1-19	271907	Tail Pipe Comp	1	
1-20	274295	Sleeve	2	
1-21	274296	Cushion B	2	
1-22	577133	Handle Fitting	1	
1-23	271908	Screw	6	
1-24	271910	Screw	1	
1-25	274297	Screw	1	
1-26	991938	Nut	2	M5 M5x30
1-27	271899	Nut	1	
1-28	274298	Washer	2	
1-29	580796	Bolt	2	
1-30	274299	Band	2	
1-31	274300	Clamp	1	Grease up
1-32	223925	Label	1	
1-33	591450	Label	1	
1-34	591449	Label	1	
1-35	271889	Spacer	1	
1-36	271890	Washer	1	
1-37	274282	Screw	1	
1-38	271914	Rod Ass'y	2	
1-39	274284	Upper Case	1	
1-40	271919	Pinion	1	
1-41	271920	Plate	1	#6001 2RS M6
1-42	270021	Drum	1	
1-43	271921	Bearing	1	
1-44	580767	Bearing	1	
1-45	991937	Grease Nipple	1	

H23F


1. MAIN BOY



Ref. No.	Part No.	Part Name	Q'ty	Remarks
1-46	274286	Lower Case	1	
1-47	271924	Plate	1	
1-48	270423	Bearing	1	
1-49	271925	Bearing	1	
1-50	271926	Crank Comp	1	
1-51	271927	Felt	1	
1-52	577136	Handle Bracket	1	
1-53	274288	Spacer	2	
1-54	274289	Cushion	4	
1-55	274290	Washer	4	
1-56	271910	Screw	5	
1-57	274291	Screw	2	
1-58	266960	Label	1	

H23F


2. ENGINE



Ref. No.	Part No.	Part Name	Q'ty	Remarks
2-1	859966	Engine	1	CE230H/08
2-2	288499	Cylinder	1	
2-3	286074	Gasket	1	
2-4	261250	Cap Screw	4	M5x20
2-5	265802	Insulator	1	New gasket required
2-6	267049	Gasket	1	
2-7	265924	Cap Screw	2	M5x25
2-8	277023	Muffler Ass'y	1	Incl.9-11
2-9	288503	Muffler Tail	1	
2-10	288504	Spark Arrestor	1	
2-11	288542	Screw	2	M4x8
2-12	277257	Label	1	H23F
2-13	266402	Cap Screw	2	M5x55
2-14	275562	Muffler Guard	1	
2-15	288542	Screw	1	M4x8
2-16	275561	Gasket	1	
2-17	275560	Under Cover	1	
2-18	267191	Cap Screw	1	M5x16
2-19	276564	Top Cover Comp	1	
2-20	286399	Knob	1	M5
2-21	288537	Crankcase	1	
2-22	280488	Bearing	2	PPL 6001
2-23	261492	Oil Seal	1	ISCD12287
2-24	261386	Oil Seal	1	ISCD12227
2-25	055185	Snap Ring	1	H28
2-26	261246	Cap Screw	3	M5x25
2-27	283379	Piston	1	
2-28	282177	Piston Ring	2	
2-29	261036	Piston Pin	1	
2-30	263957	Bearing, Needle	1	KTV81112EG01 B2
2-31	261576	Clip,Piston	2	
2-32	246387	Crankshaft/Conn. Rod Ass'y	1	
2-33	246054	Clutch Ass'y	1	
2-34	264535	Screw	2	M6x20
2-35	280144	Tapping Screw	3	4X16
2-36	277256	Label	1	H23F
2-37	275557	Fan Cover	1	
2-38	261250	Cap Screw	4	M5x20
2-39	288514	Magneto Ass'y	1	Incl.40-48
2-40	288515	Rotor/Fan	1	
2-41	288516	Ignition Coil Ass'y	1	Incl.42-48
2-42	289483	Coil	1	
2-43	289484	Spark Plug Wire Ass'y	1	Incl.44-46
2-44	289485	Spark Plug Wire	1	
2-45	272805	Connector	1	

H23F


2. ENGINE



Ref. No.	Part No.	Part Name	Q'ty	Remarks
2-46	283178	Plug Boot	1	3x10 M8
2-47	283271	Cap	1	
2-48	289486	Insulator	1	
2-49	261076	Woodruff Key	1	
2-50	261417	Nut,Rotor	1	
2-51	280381	Spacer	2	M4x25 NGK BPM8Y
2-52	261256	Cap Screw	2	
2-53	285982	Spark Plug	1	
2-54	261772	Lead	1	
2-55	283140	Grommet	1	
2-56	283171	Recoil Starter Ass'y	1	Incl.57-71
2-57	283172	Starter Ass'y	1	Incl.58-66
2-58	286363	Reel	1	Incl.64-66
2-59	286364	Cam Plate	1	
2-60	283290	Spring	1	
2-61	280931	Spiral Spring	1	
2-62	267213	Screw	1	
2-63	283291	Rope Ass'y	1	Incl.68-71
2-64	283292	Starter Rope	1	
2-65	261725	Starter Grip	1	
2-66	283293	Rope Stopper	1	
2-67	283173	Starter Pulley Ass'y	1	
2-68	283294	Starter Pulley	1	#4
2-69	280936	Ratchet	2	
2-70	283295	Spring	2	
2-71	020299	E-Ring	2	



H23F

3. CARBURETOR, FUEL TANK



Ref. No.	Part No.	Part Name	Q'ty	Remarks
3-1	277126	Carburetor Ass'y	1	Incl.2-15
3-2	268499	Pump Body	1	
3-3	247116	Purge Body	1	
3-4	262992	Cover Plate	1	
3-5	261874	Primer Bulb	1	
3-6	283905	Diaphragm, Metering	1	
3-7	262993	Gasket	1	
3-8	262994	Diaphragm,Fuel Pump	1	
3-9	282576	Gasket	1	
3-10	289396	Main Jet	1	
3-11	261871	O-Ring	1	
3-12	261876	E-Ring	1	
3-13	261658	Swivel	1	
3-14	264682	Screw	2	
3-15	262996	Screw	4	
3-16	288517	Gasket	1	
3-17	283773	Stay	1	
3-18	283771	Gasket	2	
3-19	248152	Case Ass'y	1	
3-20	277320	Element	1	
3-21	262720	Cap Screw	2	M5x55
3-22	283772	Cleaner Cover	1	Incl.25-37
3-23	281438	Knob	1	
3-24	277028	Fuel Tank Ass'y	1	
3-25	275618	Fuel Tank	1	
3-26	289046	Tank Cap Ass'y	1	Incl.27
3-27	287058	Gasket	1	Incl.29-37 Incl.30-32
3-28	289279	Fuel Pipe Pick-up Ass'y	1	
3-29	289280	Fuel Pipe Ass'y	1	
3-30	268065	Grommet	1	
3-31	289451	Breather	1	3x5x53L
3-32	261117	Clip	1	
3-33	289028	Pipe A	1	
3-34	288921	Joint	1	3x5x125L
3-35	289029	Pipe	1	
3-36	277887	Filter Ass'y	1	M5x18
3-37	261117	Clip	3	
3-38	261117	Clip	1	
3-39	269690	Cap Screw	4	
3-40	285188	Label	1	

H23F
4. ACCESSORIES



Ref. No.	Part No.	Part Name	Q'ty	Remarks
4-1	277076	Instruction Manual	1	Incl.3,4 3mm 4mm
4-2	264606	Tool Set	1	
4-3	219431	Wrench	1	
4-4	219432	Wrench	1	