


Q4015



| S/N | Part No.         | Description                   | Quantity |
|-----|------------------|-------------------------------|----------|
| 1   | 11116-A0810-0001 | Washer                        | 2        |
| 2   | 11115-A0810-0001 | Drain plug                    | 2        |
| 3   | 11120-A1010-0001 | Oil seal, crankshaft          | 1        |
| 4   | 11117-A0810-0001 | Seal                          | 1        |
| 5   | 27400-A0810-0002 | Oil sensor                    | 1        |
| 6   | 11110-A1210-0003 | Crankcase                     | 1        |
| 7   | 11130-A1010-0001 | Oil seal, regulating sway bar | 1        |
| 8   | 26113-A0810-0001 | Washer                        | 2        |
| 9   | 26112-A0810-0001 | Split pin                     | 1        |
| 10  | 26111-A1010-0001 | Regulating sway bar           | 1        |
| 11  | T312-0001        | Nut M10                       | 1        |
| 12  | 11119-A1310-0001 | O-ring                        | 1        |
| 13  | T151-0008        | Bolt M6×14                    | 2        |
| 14  | 15610-A0815-0001 | Oil plug with Seal            | 1        |
| 15  | 15611-A0815-0001 | Oil plug                      | 1        |
| 16  | 15512-A07Y3-0001 | Seal                          | 2        |
| 17  | 11211-A1010-0006 | Crankcase cover               | 1        |
| 18  | T151-0013        | Bolt M8×40                    | 7        |
| 19  | 25100-A1210-0001 | Driven gear, regulator assy   | 1        |
| 20  | 11114-A1010-0001 | Gasket, crankcase             | 1        |
| 21  | 11113-A0810-0001 | Set pin Φ8×12                 | 2        |
| 22  | 15511-A0815-0001 | Dipstick                      | 1        |
| 23  | 15510-A0815-0001 | Dipstick with seal            | 1        |
| 24  | T910-0002        | Bearing 6206                  | 1        |
| 25  | 11120-A1010-0001 | Oil seal, crankshaft          | 1        |
| 26  | T910-0005        | Bearing 6202                  | 1        |
| 27  | 12220-A0810-0001 | Bolt                          | 1        |
| 28  | 11513-A1010-0002 | Air duck                      | 1        |
| 29  | 14420-A0810-0001 | Seal                          | 1        |
| 30  | T152-0019        | Bolt M6×12                    | 1        |
| 31  | 12200-A0810-0002 | Cylinder head cover Assy      | 1        |
| 32  | 12212-A0810-0001 | Gasket, cylinder head cover   | 1        |
| 33  | 12118-A0810-0002 | Bolt                          | 4        |
| 34  | 19121-A1010-0001 | Lead wind cover               | 1        |
| 35  | 17218-A0810-0001 | Stud                          | 2        |
| 36  | 12120-A0910-0001 | Gasket, cylinder head         | 1        |
| 37  | 12117-A0810-0001 | Set pin                       | 2        |
| 38  | 12100-A1210-0002 | Cylinder head Assy            | 1        |
| 39  | 27100-A0710-0001 | Spark plug                    | 1        |
| 40  | 18214-A0810-0001 | Stud                          | 2        |
| 41  | 13313-A1010-0001 | Piston pin circlip            | 2        |
| 42  | 13311-A1210-0004 | Piston                        | 1        |
| 43  | 13312-A1010-0001 | Piston pin                    | 1        |
| 44  | T910-0005        | Bearing 6202                  | 2        |

|    |                  |                                   |   |
|----|------------------|-----------------------------------|---|
| 45 | 13116-A1210-0001 | Balancing shaft                   | 1 |
| 46 | T910-0003        | Bearing 6207                      | 1 |
| 47 | 13112-A0710-0001 | Wood ruff key                     | 1 |
| 48 | 13400-A1210-0003 | Piston ring set                   | 1 |
| 49 | 13120-A1210-0001 | Connecting rod assy               | 1 |
| 50 | 13110-A1210-0001 | Crankshaft assy                   | 1 |
| 51 | 14314-A0710-0001 | Lock nut                          | 2 |
| 52 | 14312-A0710-0001 | Sleeve                            | 2 |
| 53 | 14311-A0810-0001 | Valve rocker                      | 2 |
| 54 | 14313-A0710-0001 | Adjusting bolt for valve gap      | 2 |
| 55 | 14220-A0810-0002 | Pusher guide                      | 1 |
| 56 | 14210-A1010-0001 | Pusher                            | 2 |
| 57 | 14315-A0810-0001 | Tappet                            | 2 |
| 58 | 14100-A1210-0002 | Camshaft assy                     | 1 |
| 59 | 14412-A1210-0001 | Exhaust valve                     | 1 |
| 60 | 14411-A1010-0003 | Intake valve                      | 1 |
| 61 | 14417-A0810-0001 | Spring retainer, exhaust valve    | 1 |
| 62 | 14414-A0810-0001 | Valve spring                      | 2 |
| 63 | 14413-A1010-0001 | Spring seat, exhaust valve        | 2 |
| 64 | 14418-A1010-0001 | Valve lock clamp                  | 4 |
| 65 | 14310-A0810-0001 | Valve rocker assy                 | 1 |
| 66 | 17219-A1010-0001 | Inlet gasket                      | 1 |
| 67 | 16120-A1110-0001 | Connecting block                  | 1 |
| 68 | 16113-A1110-0001 | Carburetor gasket                 | 1 |
| 69 | 16244-A1210-0001 | Main nozzle                       | 1 |
| 70 | 16243-A1210-0001 | Main jet                          | 1 |
| 71 | 17113-A0810-0001 | Air cleaner gasket                | 1 |
| 72 | 16100-A1210-0006 | Carburetor Assy                   | 1 |
| 73 | 16622-A0710-0003 | Screw pipe clamp                  | 3 |
| 74 | 16621-A1015-0004 | Outlet pipe                       | 1 |
| 75 | T151-0006        | Bolt M8 × 25                      | 2 |
| 76 | 16630-A0710-0001 | Connector                         | 1 |
| 77 | T314-0001        | Nut M6                            | 2 |
| 78 | 16610-A0710-0004 | Filter cup                        | 1 |
| 79 | 16400-A0410-0002 | Fuel filler cap with packing ring | 1 |
| 80 | 16510-A1012-0040 | Fuel tank                         | 1 |
| 81 | 16557-A0710-0001 | Air outlet joint                  | 1 |
| 82 | 16622-A0710-0003 | Screw pipe clamp                  | 1 |
| 83 | 11513-A1010-0002 | Vent pipe                         | 1 |
| 84 | 17111-A0710-0001 | Wing nut                          | 1 |
| 85 | 17112-A1012-0001 | Air cleaner cover                 | 1 |
| 86 | 17124-A1010-0001 | Filter element                    | 1 |
| 87 | 17114-A1210-0001 | Air cleaner aeration cover        | 1 |
| 88 | 17200-A1010-0002 | Air cleaner housing               | 1 |
| 89 | T152-0011        | Bolt M6 × 28                      | 1 |

|     |                  |                              |   |
|-----|------------------|------------------------------|---|
| 90  | 17121-A0810-0001 | Washer                       | 1 |
| 91  | T314-0001        | Nut M6                       | 2 |
| 92  | 17100-A1212-0005 | Air cleaner assy             | 1 |
| 93  | 17111-A0712-0001 | Air cleaner cover nut        | 1 |
| 94  | T354-0001        | Nut M8                       | 5 |
| 95  | 18215-A0810-0001 | Exhaust pipe gasket          | 1 |
| 96  | 18117-A0810-0003 | Exhaust pipe                 | 1 |
| 97  | 18217-A0810-0001 | Muffler gasket               | 1 |
| 98  | 18000-A1012-0009 | Muffler assy                 | 1 |
| 99  | 27300-A0712-0001 | Engine switch                | 1 |
| 100 | 19314-A0810-0001 | Wire grommet                 | 1 |
| 101 | 19316-A0810-0002 | Clip                         | 1 |
| 102 | 16628-A0810-0001 | Plastic clip                 | 1 |
| 103 | T152-0019        | Bolt M6 × 12                 | 5 |
| 104 | 19211-A1010-0041 | Fan hood assy                | 1 |
| 105 | T152-0036        | Bolt M6 × 8                  | 3 |
| 106 | 23200-A1011-0004 | Recoil starter               | 1 |
| 107 | 23100-A1012-0027 | Recoil starter assy          | 1 |
| 108 | 26117-A1010-0001 | Back spring                  | 1 |
| 109 | 26116-A0710-0001 | Lock bolt                    | 1 |
| 110 | 26114-A1010-0001 | Regulating arm               | 1 |
| 111 | 26118-A1010-0001 | Fine regutaling spring       | 1 |
| 112 | 26115-A1010-0001 | Pulling rod                  | 1 |
| 113 | T311-0002        | Nut M6                       | 1 |
| 114 | 26200-A1010-0001 | Regulating frame assy        | 1 |
| 115 | 23317-A0810-0002 | Nut M16 × 1.5                | 1 |
| 116 | 23316-A1010-0002 | Starting flange              | 1 |
| 117 | 19111-A1210-0001 | Flywheel fan                 | 1 |
| 118 | 23300-A1114-0001 | Flywheel                     | 1 |
| 119 | T152-0034        | Screw M6 × 25                | 2 |
| 120 | 27220-A1010-0001 | Spark plug cap               | 1 |
| 121 | 27200-A1110-0001 | Ignition coil assy           | 1 |
| 122 | 55550-EC510-0001 | Wand assy                    | 1 |
| 123 | 55100-EC510-0001 | Frame                        | 1 |
| 124 | 55511-ED910-0002 | High pressure pipe           | 1 |
| 125 | 45420-EC510-0001 | Wheel                        | 2 |
| 126 | T315-0002        | Nut (M12)                    | 2 |
| 127 | 55600-ED910-0002 | High pressure pump assembly  | 1 |
| 128 | 55510-ED910-0001 | Water Outlet Pipe Components | 1 |
| 129 | 31200-EC510-0004 | Control panel                | 1 |
| 130 | 31225-B9140-0002 | The ignition switch          | 1 |
| 131 | 32480-BB140-0002 | Armrest latch assembly       | 2 |
| 132 | 55530-E8310-0003 | Inlet pipe assembly          | 1 |
| 133 | 55125-E7310-0001 | Nozzle rubber sleeve         | 5 |